

Instructions for Use: Leak Tester Tester

Brand Name of Product	Leak Tester Tester	
Generic Name of Product	Leak Tester (LTT)	
Product Code Number(s)	LTT4000, LTT-1001, LTT-1002, LTT-1003, LTT-1004	
Intended Use	To test the pressure of air (i.e., pounds per square inch [psi or lb/in²]) of a leak tester.	
Range of Applications for Product	Testing pump and the connector functionality of leak testers.	
Key Specifications of Product	The LTT4000 includes one of each Leak Tester Tester: • LTT-1001- Olympus® MU-1 pump • LTT-1002- Olympus® handheld leak tester connections, and Olympus® ALT-Pro • LTT-1003- PENTAX® handheld leak tester connections • LTT-1004- KARL STORZ handheld leak tester connections.	

Shipping & Storage	
Shipping Conditions & Requirements	N/A
Storage Conditions	Store the LTTs to prevent damage to the venting ports and factory calibrated gauge.
Packaging Contents	N/A
Shelf Life	N/A

Instructions for Using Product		
Description of Use(s)	To verify the accuracy of air pressure provided by automated and handheld endoscope leakage testers.	
Preparation for Use	 LTT Gauge Inspection Before Use (NOTE: This is to be performed for all LTT gauges before they are used.) Inspect LTT for damage (includes verifying the pressure gauge reads zero prior to use). (Fig. 6). If the gauge is showing pressure (not at zero), pull up on the blue cap atop of the gauge. (Fig. 7). a. This process will open the vent plug and relieve the internal pressure changes in the gauge case. b. Malfunctioning gauges that do not tare to zero requires returning for evaluation. 	

Diagrams (drawings, pictures)



Olympus[®] MU-1 LTT-1001 Figure 1



Olympus® Handheld and MB-155 and ALT-PRO LTT-1002 Figure 2



PENTAX® Handheld LTT-1003 Figure 3



KARL STORZ Handheld LTT-1004 Figure 4



Figure 5



Figure 6



Figure 7



Figure 8



Figure 9



Figure 10



LTT-1002 Figure 11



Figure 12



Figure 13



Figure 14



Figure 15

Olympus® MB-155 Leak Tester





Figure 16

Figure 16A

Figure 17

Steps for Use of Product

NOTE: The unit of measure (e.g., PSI or mmHg) is identified on the gauge face of handheld endoscope leak testers. (**Fig. 5**).

Olympus® MU-1

- 1. Install the LTT into the socket of the MU-1. (Fig. 8).
- 2. Turn the power switch to the *On* position to pressurize the LTT.
- 3. Record the pressure reading on the test figure gauge.
 - a. *Passing:* Pressure should be above > 4.0 psi to be passing.
 - b. Not Passing: Pressure should **not** be ≤ 4.0 psi or below (hold for at least 30 seconds), which is considered a failure. In this case the MU-1 should not be used.
- 4. Turn off the power switch and remove LTT from the MU-1.
- 5. Record the pressure reading from the LTT gauge.

Olympus® Alt-Pro

- 1. Install the MAJ-2009 leak test air tube into the tube connector of the Alt-Pro. (Fig. 9).
- 2. Connect the LTT-1002 to MAJ-2009 leak test air tube.
- 3. Set the Alt-Pro to *Manual* testing, then press *Start* to pressurize the LTT. (**Fig. 10**).
- 4. The passing pressure range should be 2.9- to 4.1 psi (hold for at least 30 seconds).
 - a. If the psi is not in this range, it is considered a failure, and the leak test air tube should be replaced.
 - b. Repeat the above steps 1–4 on the alternate leak test air tube.
- 5. Record the pressure reading from the LTT gauge.

Handheld Leak Testers:

- 1. Attach handheld leak tester to the appropriate LTT. (Fig. 12).
- 2. Place handheld leak tester in the pressurized position. (Fig. 13).

3. Pump the handheld leak tester's inflation bulb until the needle holds steady in the correct pressure zone. The LTT pressure gauge should correlate to the unit of measurement on the handheld leak tester (see **Chart 1 for conversions**). (**Figs. 14 and 15**).

\boldsymbol{C}	h	a		4	1
	•	и	т.		

	Charti	
Unit of Pressure	Pressurize to	Correlation to LTT Gauge
kPa	25 units	3.6 psi on test fixture
mmHg	160 units	3.0 psi on test fixture
lb/in² (psi)	3 psi	3.0 psi on test fixture

NOTE: Test fixture gauge has an allowable variance of 0.24 psi.

- 4. Ensure the needle holds steady for 1-minute.
 - a. If the needle falls or pressure cannot be maintained during the 1-minute timeframe, your handheld tester is faulty and does not hold a pressure. *Do not use; replace.*
 - b. Maintaining pressure for 1-minute means your handheld tester is acceptable for testing an endoscope.
- 5. Release the pressure on the handheld leakage tester and allow 10 seconds to completely depressurize the LTT (test fixture).
- 6. Disconnect the leak tester from the LTT.
- 7. Record the pressure reading from the LTT gauge.

Olympus[®] MB-155 Leak Tester Cable (coiled)

- 1. Install the MB-155 cable into the socket of the MU-1. (Fig. 16).
- 2. Connect the LTT1-002 to MB-155 leak tester cable. (Fig. 16A).
- 3. Turn the power switch to the *On* position to pressurize the testing device.
- 4. The pressure range should be 2.9- to 4.1 psi (hold for at least 30 seconds). (Fig. 17).
 - a. If the psi is not in this range, it is considered a failure.
 - b. Do not use and remove it from service.
- 5. Turn the power switch Off.
- 6. Depressurize the connection at the pump and remove LTT from MB-155.
- 7. Record the pressure reading from the LTT gauge.

Interpretation of Test Results	N/A
Contraindications of Test Results	N/A
Documentation	N/A
Special Warnings and Cautions	 If the gauge becomes inadvertently submerged in fluid or the Leak Tester Tester (LTT) is dropped, the LTT should be returned to validate proper calibration. Submerging, dropping, or mishandling LTT may damage the accuracy of the gauge.
Disposal	N/A

Reprocessing Instructions	
Point of Use	N/A
Preparation for Decontamination	N/A
Disassembly Instructions	N/A
Cleaning – Manual	Wipe with an IPA wipe.

Cleaning – Automated	N/A
Disinfection	N/A
Drying	N/A
Maintenance, Inspection, and Testing	Each unit should be returned to Healthmark annually for recalibration.
Reassembly Instructions	N/A
Packaging	N/A
Sterilization	N/A
Storage	Store the LTTs to prevent damage to the venting ports and factory calibrated gauge.
Additional Information	N/A
Related Healthmark Products	N/A
Other Product Support Documents	ProSys™ Brochure, ProSys™ Price List
Reference Documents	ISO 8600-7
Customer Service Contact	Healthmark, A Getinge Company 18600 Malyn Blvd. Fraser, MI 48026 1-586-774-7600 healthmark@hmark.com hmark.com